

Fitting the Rear Door Strengthening Kit for the Masai Large Spare Wheel Carrier.

1. Locate the uprights as in the first photo.
2. Bond or rivet the uprights into position.
3. Photo 2 - Use the square plates to cover the old spare wheel carrier holes, if there were any. You can use a bonding adhesive, rivets or nuts and bolts to secure the plate to the inside of the back door.

