

## **FITTING INSTRUCTIONS**

Dynamat Rear Floor -Defender 90 Models - Pre 2007

Part No. MA028097

2	3	3	
2	4		4

## **Fitting Advice**

- Edges can be sharp, please protect your hands.
- Ensure all surfaces are clean.
- With backing paper in place, locate area. Peel back approximately 1" of backing paper from an edge and stick into place. Once happy, peel the remaining backing paper and smooth over.
- Please note that some panels may require additional cutting.

