

# MASAI STEERING GUARD

ILLUSTRATED FITTING MANUAL



You will need:

- General workshop tools
- Torx wrench (Optional)
- Penetrating oil (Optional)



1. Remove the highlighted nuts from your vehicle in order to attach the left hand side bracket to the chassis.



2. You may need to use a suitable penetrating oil to remove the nuts. If they are not present, use the nuts provided with the kit instead.



3. Repeat the process with the right hand bracket as shown above.



4. Adjust the distance between the left and right hand brackets to fit the holes on the back of the steering guard.



5. The brackets should fit to the rear of the steering guard as shown above.



6. Fasten the outermost bolts using a spanner or a torx wrench.



7. Finally, fasten the innermost bolts using a spanner or a torx wrench. You can use an appropriate adhesive on the bolts to keep them in place, but this step isn't essential. The installation is now complete!

## Customer Feedback

Your feedback is very important to us.

We would love to hear any suggestions or recommendations you may have about the Masai product range. If you have any feedback you think may help us improve the services or products we offer, then please use the details found at the bottom of this page to contact us.

Thank you for choosing Masai.



Unit 5, Eastern Park, Eastern Avenue, Lichfield,  
Staffordshire, WS13 7SY. United Kingdom.  
Tel: +44(0)1543-254507 Fax: +44(0)1543-418665  
Email: [info@masai.co](mailto:info@masai.co)

[www.masai.co](http://www.masai.co)