

Kit contents -

- 1 x Dog guard
- 2 x Mounting feet
- 2 x Stiffening plates
- 4 x M8 set screws
- 4 x M8 nuts
- 8 x M8 flat washers
- 4 x M8 spring washers
- 2 x M8 thumbscrews
- 1 x Top bracket
- 2 x 10 x screws - discard on pre-1989 models

- > Attach mounting feet to dog guard using thumbscrews.
- > Tilt front seat and slide forward.
- > Pass assembled dog guard into vehicle with mountings anchored forward and resting on top of bulkhead.
- > Centralise dog guard in vehicle and mark rivet heads (visible through slots in feet).
- > Remove dog guard and drill out rivets using M9 (11/32") drill.
- > Attach top bracket onto locating tab on top edge of dog guard (with angled face rearwards).
- > Refit dog guard and mount in position using fixings supplied (see illustration) and tighten all bolts.
- > Lift top bracket until contact with headlining is made and mark 2 holes.
- > Drill through headlining and roof channel using 4.0mm drill **TAKING CARE NOT TO DRILL THROUGH THE ROOF.**
- > Fasten top bracket into position using self tapping screws.

Note - If alarm sensor fitted, locate aperture behind headlining approx 70mm up and 130mm forward of present position. Relocate sensor and cover original aperture.

